



SLX Frequency Codes 08/2011

www.shure.de
www.shure.co.uk
www.shure.nl

Q24: 736 - 754 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9	Group 10	Group 11	Group 12	Group 13
1	736,475	736,550	736,300	736,250	742,125	750,150	736,175	737,250	736,775	736,225	737,750	736,775	736,225
2	738,225	738,075	737,575	737,975	743,225	751,250	737,700	739,500	738,975	738,775	740,250	738,225	738,025
3	739,325	739,200	739,200	739,200	744,925	752,700	738,800	742,750	740,500	740,700	743,750	740,900	741,100
4	740,775	740,900	740,325	740,725	746,225	753,825	740,425	744,500	741,700	743,000	746,500	742,100	742,300
5	742,575	742,150	741,775	741,825	748,025		741,725	747,250	745,500	744,225	748,250	745,500	748,000
6	744,075	744,150	744,775		749,525		750,125	750,750	748,500	746,025	751,500	748,500	749,100
7	746,250	745,725	746,850				751,275	753,250	750,100	750,300	753,750	752,025	751,000
8	747,925	747,000	748,200				752,725		752,775	752,975		753,500	752,225
9	749,175	748,750	749,975				753,850						
10	751,050	750,875	751,125										
11	752,575	752,550	752,625										
12	753,800	753,850	753,725										
	Full Range max. # of compatible frequencies (option 1)	Full Range max. # of compatible frequencies (option 2)	Full Range max. # of compatible frequencies (option 3)	European TV channel 54 optimized 736 - 742 MHz	European TV channel 55 optimized 742 - 750 MHz	European TV channel 56 optimized 750 - 754 MHz	European TV channels 54 and 56 optimized 736 - 742 MHz 750 - 754 MHz	France preferred: User Group A (option 1)	France preferred: User Group B (option 1)	France preferred: User Group C (option 1)	France preferred: User Group A (option 2)	France preferred: User Group B (option 2)	France preferred: User Group C (option 2)