TABLE SHOWING CURRENT AVAILABILITY OF NL TV CHANNELS FOR USE BY WIRELESS MICROPHONES AND IEMS.

TV Channel	21	22	23	24	25	26	27
Frequency Range	470- 478MHz	478- 486MHz	486- 494MHz	494- 502MHz	502- 510MHz	510- 518MHz	518- 526MHz
TV Channel	28	29	30	31	32	33	34
Frequency Range	526- 534MHz	534- 542MHz	542- 550MHz	550- 558MHz	558- 566MHz	566- 574MHz	574- 582MHz
TV Channel	35	36	37	38	39	40	41
Frequency Range	582- 590MHz	590- 598MHz	598- 606MHz	606- 614MHz	614- 622MHz	622- 630MHz	630- 638MHz
TV Channel	42	43	44	45	46	47	48
Frequency Range	638- 646MHz	646- 654MHz	654- 662MHz	662- 670MHz	670- 678MHz	678- 686MHz	686- 694MHz
TV Channel	49	50	51	52	53	54	55
Frequency Range	694- 702MHz	702- 710MHz	710- 718MHz	718- 726MHz	726- 734MHz	734- 742MHz	742- 750MHz
TV Channel	55	56	57	58	59	60	61
Frequency Range	742- 750MHz	750- 758MHz	758- 766MHz	766- 774MHz	774- 782MHz	782- 790MHz	790- 798MHz
TV Channel	62	63	64	65	66	67	68
Frequency Range	798- 806MHz	806- 814MHz	814- 822MHz	822- 830MHz	830- 838MHz	838- 846MHz	846- 854MHz
TV Channel	69	70					
Frequency Range	854- 862MHz	863- 865MHz					
	Interleaved spectrum available for wireless microphones and IEM's. Harmonized European spectrum only 2 MHz of Ch. 70 is available and with max. power of 10 mW.						

Cleared spectrum as result of DD1 use for wireless microphones and IEM's not allowed after 1-1-2016.

Advice against use of this Spectrum, due to future development (DD2) after 2020.

In use with radio astronomy, occasionally special permit possible.